




M2 Antenna Systems, Inc. Model No: 303CP26



SPECIFICATIONS:

Model	303CP26	Power Handling	1.5 kW
Frequency Range.....	298 To 308 MHz	Boom Length / Dia.....	140.625" / 1"
*Gain	15.14 dBic	Maximum Element Length.....	20"
Front to back	20 dB Typical	Turning Radius:.....	Call
Beamwidth	30° Circular	Stacking Distance.....	Call
Feed type	"T" Match	Mast Size.....	1-1/2" to 2" Nom.
Feed Impedance.....	50 Ohms Unbalanced	Wind area / Survival	0.6 Sq. Ft. / 100MPH
Maximum VSWR.....	1.5:1	Weight / Ship Wt.....	5 Lbs. / 7 Lbs.
Input Connector.....	"N" Female		

***Subtract 2.14 from dBi for dBd**

FEATURES:

The 303CP26 is a practical sized, yet high performance circular polarized antenna with a remarkably clean pattern. The pattern is important in order to match the antenna's noise temperature with modern low noise preamps. This antenna is ideal for satellite work but is also excellent for terrestrial uses.

The CNC machined driven element module is O-ring sealed and weather tight for low maintenance and long-term peak performance. Internal connected are encapsulated in a space-age silicone gel that seals out moisture and improves power handling. The 3/16" 6061-T6 rod elements are centered to minimize interaction and maintain good ellipticity. Insulators are UV stabilized and locked in place with stainless keepers. Rugged construction, uncompromising performance for the boom length.

303CP26 ASSEMBLY MANUAL

Before beginning assembly, read over the parts list and check for missing or damaged parts. Contact the M2 Antenna Systems, Inc. directly at 559-432-8873 if any discrepancy is found.

Tools required: A medium size flat blade screwdriver, an 11/32 nut driver or equivalent, a 1/2 inch wrench or nut driver, a 7/16 inch wrench and a tape measure.

1. The driven element is partially assembled at the factory. Starting 11-3/8" (11.375") from the rear of the female "F" connectors point toward the front of the antenna. Secure with an 8-32 x 1-1/4" screw. Next, slide the 3/16 x 18.0 inch long rod through the open holes just below it and add two black button insulators. Center the rod in the boom. Add the shorting blocks, positioning them at the ends of the shorter rod elements. When everything is adjusted, tighten up the set screws.
2. Repeat this operation for the second driven element, mounting it at 20-3/8" (20.375") from the rear and with the two "F" connectors facing the rear driven element just installed and on the left side of the boom per the sketch. Proper positioning per the sketch will guarantee RIGHT HAND CIRCULARITY.
3. Assemble the boom per the antenna dimension sheet, secure the joints with the 8-32 x 1-1/4" screws, lockwasher and nuts. Final tightening and alignment will be done after the elements are all in place.
4. Now mount the phasing block 9-1/4 inches from the rear of the boom using an 8-32 x 1/4" screw. Position the block on the same side of the boom as the rear driven element so the large "N" connector is facing to the rear.

REFER TO THE CABLE ASSEMBLY SKETCH FOR STEPS 6, 7 & 8.

5. Connect the two 14.5 inch long balun cables to the two close spaced connectors on each driven element block. Tighten the connectors first by hand and then gently but firmly with a 7/16 inch end wrench. TO PREVENT POSSIBLE CABLE DAMAGE hold the body of the connector with pliers so it doesn't rotate during this final tightening operation.
6. Connect the long, 22-1/2" phasing cable to the single TOP connector on the FRONT driven element and route the cable back to the side connector on the phasing block. Again, tighten both ends first by hand and then finally with the 7/16 inch wrench.
7. Connect the short 7-1/2 inch phasing cable to the single connector on the rear driven element block and route the cable to the in line connector on the phasing block. Tighten as before.
8. Once the cables are all in place form them neatly against the boom and hold in place with the black nylon ties. In places where director rod elements will come through the boom, do not tighten the nylon ties all the way so the cables may be moved slightly for clearance around the rod elements.

INSTALLING THE ELEMENTS

9. Separate the rod elements into two (2) sets. Using just one set, install the 18-7/8" rod element in 5/16 inch diameter hole 5 inches from the rear of the boom. Use the black button insulators on either side where the element passes through the boom. At this time just position the element near center. Final centering can be done later when all the elements in one plane are in place.
10. The elements taper in length so continue installing the rods down the boom using the button insulators as described in step #10.
11. When all the elements in one plane are in place, start at one end using a tape measure: center each element to 1/16 inch or better. We recommend you DO NOT install the keepers at this time, just center each element. When centering is complete, stand at the end of the boom and sight down the tips of the elements noting any irregularities. The tips should form a gentle curve, and each side should look like a mirror image of the other. This is just a crude check to catch major errors or any irregularities. Correct if found.

303CP26 DIMENSION SHEET

ELEMENT SPACING			ELEMENT LENGTH	
H	V		H	V
5.0			18.875	
11.375			18.0	
16.125	14.0		18.875	
	20.375		18.0	
22.75	25.125		17.375	
31.125	31.75		17.187	
40.875	40.125		17.0	
51.688	49.875		16.813	
63.375	60.688	57.5	16.625	
75.75	72.375		16.50	
88.813	84.75		16.375	
102.375	97.813		16.25	
116.50	111.375	113.0	16.125	
	125.50		16.062	
131.062			16.0	
	140.062		16.0	

303-C26 CROSS-POLARIZED YAGI
Mike Staal 5-10-89

303CP26 ASSEMBLY MANUAL

12. The stainless steel element keepers are stiff so grasp the element firmly while sliding the keepers in place. USE THE 3/8 X 3 TUBE TO AID IN THE INSTALLATION. Double check your centering dimensions and then push the keepers up tight against the button insulators.

13. Repeat steps 10 through 13 for the other set of elements.

14. Now that all the elements are in place, sight down the boom looking for element alignment irregularities around the boom splice joints. Align and tighten.

15. Pick up the boom and find the weight balance point. Remember the feedline will attach at the rear and add a bit more weight on that end. Position the boom to mast plate accordingly, attaching it to the boom with the 1-1/8 inch U-bolts, cradles and nuts.

16. Circular polarized antennas such as this antenna must be mounted on non-metallic masts or support booms and the feedlines must run off the back of the boom so as not to disturb the standing wave ratio and the circular properties of the antenna. If this antenna is to be mounted as a pair of transmit-receive antennas a 6 to 8 foot long by 1-1/2 inch diameter crossboom is recommended. When attaching the main 50 Ohm feedline, tape or nylon tie it securely to the rear stub of the boom to remove stress on the male "N" connector.

THIS ANTENNA HAS BEEN CAREFULLY MANUFACTURED BY:

M2 Antenna Systems, Inc.
4402 N. Selland Ave.
Fresno, CA 93722
(559) 432-8873 Fax (559) 432-3059
www.m2inc.com email: sales@m2inc.com

303CP26 PARTS & HARDWARE

303CP26 PARTS LIST

DESCRIPTION	QTY
BOOM SECTION, 1.0" X .058 X 60" SOE	1
BOOM SECTION, 1.0" X .058 X 58" SOE	1
BOOM SECTION, 1.0" X .058 X 27.625" STR	1
ELEMENT SET, 3/16" X SEE DIMENSION SHEET	26
DRIVEN ELEMENT ASSEMBLY	2
PHASING BLOCK.....	1
BALUN, 14.5" RG-6	2
PHASING CABLE, 22.5" RG-6	1
PHASING CABLE, 7.5" RG-6	1
BOOM TO MAST PLATE, .188 X 4" X 6"	1
U-BOLT, 1-1/2" AND CRADLE	2
U-BOLT, 1-1/8" AND CRADLE	2
ASSEMBLY MANUAL.....	1
HARDWARE BAG	
SHORTING BARS, 1/4 X 3/4 X 1-1/2 ALUMINUM.....	4
BUTTON INSULATORS	52
ELEMENT KEEPERS	52
SCREW, 8-32 X 1-1/4 SS	7
SET SCREW, 8-32 SS.....	8
LOCKWASHER, SPLIT-RING #8	4
NUT, 8-32 SS.....	4
NUT, 5/16-18 SS.....	8
LOCKWASHER, 5/16-18 SS	8
NYLON TIE	5
PUSH TUBE, 3/8 X 3"	1
ALLEN WRENCH, 5/64	1

M² ANTENNA SYSTEMS, INC.

4402 N. SELLAND AVE.

FRESNO, CA 93722

(559) 432-8873 FAX: 432-3059

www.m2inc.com Email: sales@m2inc.com